


Changes in stem water content result in underestimated sap flux density with thermal dissipation probes (TDP)

Lidewei L VERGEYNST, Kathy STEPPE




TDP

Convective cooling of heated needle is measure for sap flux density.

The temperature difference between a heated and reference needle (ΔT) is compared with the maximal ΔT (ΔT_{\max}) when there is no sap flow at night.

ΔT_{\max} is assumed to be constant.



Problem

TDP often underestimates sap flux density.





Findings

Water content of the stem decreases during the day.

ΔT_{\max} increases with decreasing water content.

Conclusion

Daily decrease in water content in the stem results in underestimation of sap flux density with TDP.



Laboratory of Plant Ecology
Faculty of Bioscience Engineering
Ghent University

Coupure links 653
B-9000 Ghent, Belgium
T +32 9 264 61 26

Lidewei.Vergeynst@UGent.be